

Wiper Delete Kit Installation (79-93)



To Remove each wiper arm:

1. Lift the wiper arm up to the locked position. Using a flat headed screwdriver, move the locking tab to the locked position.

2. (Driver side) Remove rubber grommet by simply pulling up on it.

3. (Driver side) Install cover and tighten set screw. (Passenger side) Align notch in wiper delete with forward facing rib on wiper post and tighten set screw.