



Mustang Gauge Bezel Installation Instructions

Tools Needed:

- Razor Blade
- 2mm Allen Wrench
- Flat Head Screw Driver
- T15 Torx Bit and 1/4 inch Ratchet
- Long Extension for 1/4 inch Ratchet



Installation Instructions - Be Very Careful Not to Scratch the Factory Lens

1. Use Torx bit to remove the 2 screws from the underside of the dash above the gauges.



2. Use an allen wrench or flat head screw driver to remove the factory headlight knob.



3. Now remove the factory gauge bezel from the dash board.

4. Remove the black screws holding in the factory gauges with the Torx bit and long extension.

5. After removing the screw pull the gauges forward and tilt the bottom up.



6. Now you should be able to see the electrical plugs on the backside of the gauges.

7. You can squeeze the plugs to release them from the gauge assembly.



8. Now remove the gauges from your mustang and work on them on a counter top.
9. Unscrew all the gold screws and gently lift the plastic gauge face off the speedo gauges.



10. Look closely at the Chrome Gauge Ring Bezels where the snap tabs are.

11. You will need to remove some plastic on the gauges bezel with a razor to lock them in place.



12. This is the best way to ensure they lock in place and never come loose. Very easy procedure.

13 Now twist the gauge ring bezels and slip them into the factory bezel between the black and clear plastic.

14. Once they are all securely locked in place then you can put everything back together.

15. Congratulations you now have one of the Hottest Interior Upgrades Available!

