



21-24 Ford Bronco Rear Tow Hook

1. Remove the plastic retainer that is between the mounting bolts by prying it out with a panel removal tool or a flat screwdriver.
2. Use an 18mm socket to remove the factory bolts from the factory rear tow hook.
3. Remove tow hook.
4. Install UPR tow hook using the factory hardware in the reverse order of removal. Torque the bolts to 50 ftlbs.

Product Liability Statement: The purchase of the product, manufactured by UPR Products Inc. completes an agreement between UPR Products Inc. and the customer. UPR Products Inc. assumes no liability for damages or injury incurred by the buyer of this product. The purchaser or user of this product is responsible for the proper disposal of any hazardous materials (oil catch can contents). The buyer has complete responsibility for the installation, use and upkeep of this product.