



2015-17 Mustang UPR Plug n Play™ Breather Tank Instructions

1. Firmly pull up on each side of the engine cover to lift it off for the installation
2. Now you will need to remove the radiator cover by using a small screwdriver to lift each push pin and the remove the female side of the push pin as well (Keep a small box to put all the parts into so you don't lose anything)
3. You can now see the mounting location and remove the bolt or stud that is located there. (Right above the plastic tab that locates the front bumper bracket as pictured)
4. Take the mounting bracket and disconnect it from the UPR Plug n Play™ Breather tank and you can now install it in the location you just removed the factory bolt or stud from.
5. The bracket comes pre-assembled in the correct position and just needs the long bolt installed to be ready to mount the UPR Plug n Play™ Breather tank. (Unclip the harness beneath the breather tank to move it over and press it down for clearance)
6. Remove the Passenger side PCV line at the valve cover and the front of the intake manifold. (You slide the small clip on the connector to release it)
7. Now attach the UPR Plug n Play™ Breather Tank to the valve covers. (You will need to route the Y around the back of the engine if you have the dual kit.)
8. Make sure all the connections are securely pushed on and tight. Re-install the engine cover by lining it up and then pressing down to snap it in place. Re-install the radiator cover.
9. You should check the UPR breather tank every 500 to be able to determine the frequency you will need to check the can to be emptied. This will also let you know how much to add to your engine as you drain the oil your UPR breather tank collects

Never use the oil again that is collected in your breather tank.







