



2005-2017 Dodge UPR Pro-Series Adjustable Front Sway Bar Linkage Install

1. Raise the front of chassis with jack and support with jack stands according to your owner's manual for the appropriate jacking points.
2. Remove your driver side front wheel.
3. Remove the factory nut on the top and bottom of the front sway bar link (see first Image below). You will have to hold the stud at the center or on the end to keep it from spinning while removing the nut on both ends.
4. Match up length of the UPR Pro-Series adjustable sway bar linkage to the stock linkage as a starting point.
5. Install the link bar on the car with the 4 hat bushings installed in the heim joints. The taller hat bushing goes against the sway bar and the body and the short bushing goes on the outside. Use the provided bolts and nuts to install the sway bar linkage (see second Image below).
6. Reinstall your wheel and repeat steps 2 through 5 on the passenger side.
7. You can now make adjustments to your sway bar linkage. Typically if you have lowered your vehicle you would want to shorten the linkage to bring the sway bar back to its original position.
8. Lower your front chassis back on the ground.
10. Make sure to tighten the jam nuts after any adjustments have been made to your linkage arms.

