



UPR 2015-2017 Mustang 5.0 Emblem Installation & Removal Tips

(UPR Tips to ensure professional results)

Removing the factory emblems to install NEW emblems and give your Mustang a brand new look is without a doubt one of the most rewarding exterior upgrades available. Or the best way to set your car apart from just another off the showroom floor FORD Mustang.

The correct process to remove and install 5.0 emblems from your Mustang.

Step 1 - To safely remove the emblems you will need dental floss or fishing line and gently work it up and down against the adhesive while keeping pressure so it will cut the adhesive.

(You will have to take your time to be sure you are neatly cutting and lifting the emblem)

Step 2 - Now you will need gently pick and rub off as much as possible. Then you will need to use a rag with some goo gone and get every bit of adhesive off.

(Lastly, you can polish the area for a perfect finish)

Step 3 - Use rubbing alcohol and be sure to get any wax off from the emblem installation surface for a long lasting installation.

Step 4 - Now making sure the adhesive is securely in place before installing your emblem by lining it up with the edge as desired before your final application

Step 5 - Now make sure the alignment is where you want it and remove the adhesive backing and press and hold it firmly in place for 1 minute.

(To remove any imperfections from the emblem surface you simply wax and wipe the emblem down)

- **UPR emblem maintenance tips**

Always, be sure to use the same wax you use on your Mustang painted surface to wax and maintain the painted surface of your Mustang emblem. (**Not required for matte colors**)

- **Most important step for a perfect finish**

During handling, shipping and installation these emblems can get superficial marks that will need to be wiped off by waxing the emblems as a last step to finalize the installation.